
SA039100 – Sander 1600 Wheel Upgrade Kit Instructions

Kit Components:

1. RV009600 (Qty 2) –Wheel, Performa, 6” Grey
2. 85383A (Qty 2) – Screw 10-32 x ¾” Pan HD
3. PA006100 (Qty 1) – Loctite, Med. Str, 242, .5ml

Tools Required:

1. #2 Phillips Screwdriver

Instructions:

1. Unplug machine from power source.
2. Using a #2 Phillips screwdriver, remove the screw securing the wheel.



3. Remove the Wheel and nylon spacer. Keep the flat washer for use later.



- The new wheels should have two bushings each. Install in wheels and slide on axle.



- Put washer on screw then apply supplied Loctite 242. Thread screw in axle and tighten.

